

BROMINE - CHLORIDE



The total chelant determination is limited to 50 ppm or 10 drops of titrant. The test is pH dependent. Because the titrant is very acidic, it can decrease the pH of the endpoint.

INDIVIDUAL TEST KITS

ORDER CODE MODEL	TEST SYSTEM (DETAILED ON PAGES 6-7)	RANGE/SENSITIVITY	# OF TESTS (# REAGENTS)	SHIPPING CODE (WEIGHT/LBS)
BROMINE (Continued)				
6824 LP-29	DPD Tablet Bromine in Chlorine Octet Comparator	0.2, 0.4, 0.6, 0.8, 1.0, 1.5, 2.0, 3.0 ppm Br	50 (3)	NH (1)
3672-01 DC1200-BR	DPD Tablet Colorimeter	0-7.0 ppm/0.05 ppm Br	100 (1)	NH (5)
3624 CL-BR	FAS Chlorine or Bromine Direct Reading Titrator	0-10 ppm/0.2 ppm Cl or Br 0-100 ppm/2 ppm Cl or Br	50 at 10 ppm (3)	NH (1)
CADMIUM A dithizone extraction of cadmium produces a pink to red color.				
7839-01 P-53	Octet Comparator	0.1, 0.2, 0.3, 0.4, 0.5, 0.6, 0.8, 1.0 ppm Cd	20 (4)	HF (1)
CALCIUM (See Hardness)				
CARBON DIOXIDE A standard alkali is used to titrate samples to the phenolphthalein endpoint.				
7297-DR PCO-DR	Direct Reading Titrator	0-50 ppm/1.0 ppm CO ₂	50 at 50 ppm (2)	R1 (1)
7525 PCO-DC	Dropper Pipet	1 drop = 2.5 ppm CO ₂	50 at 50 ppm (2)	R1 (1)
CAUSTIC A sample is reacted with barium to precipitate any carbonates, then is titrated with a standard acid to the phenolphthalein endpoint. The 7181 includes a 1:10 dilution, resulting in a 1 drop = 0.1% or 1 drop = 1% equivalence.				
7516-DR-01 DCA-DR	Direct Reading Titrator	0-10%/0.2% NaOH	50 at 10% (4)	R1 (1)
7181	Dropper Bottle	1 drop = 0.1 or 1% NaOH	50 at 10% (3)	R1 (1)
CHELANT Free chelant is determined by using the back titration of a hardness test, with magnesium as the titrant. Since bismuth will displace other metals from chelants, it is used for total chelant determinations. Both tests use different sample sizes to determine NTA or EDTA.				
7144	Free Chelant Dropper Bottle	1 drop = 2 ppm EDTA 1 drop = 2 ppm NTA	100 (3)	R1 (1)
7143	Total Chelant Dropper Bottle	1 drop = 5 ppm EDTA 1 drop = 5 ppm NTA	100 (3)	HF (1)
CHLORIDE The argentometric method is used with all kits. This employs a chromate indicator and silver nitrate titrant. Hydrogen peroxide is included with kits 7172 and 7247 to eliminate sulfite interference.				
3468*† DR-C	Direct Reading Titrator	0-50 ppm/1 ppm Cl ⁻	50 (2)	NH (1)
4503-DR-01 PSC-DR	Direct Reading Titrator	0-200 ppm/4 ppm Cl ⁻ 0-20,000 ppm/400 ppm	50 at 200 ppm (4)	R1 (1)

CHLORIDE - CHLORINE

DPD can be partially or completely bleached by chlorine or bromine concentrations greater than 6-10 ppm, depending on the sample size.



ORDER CODE MODEL	TEST SYSTEM (DETAILED ON PAGES 6-7)	RANGE/SENSITIVITY	# OF TESTS (# REAGENTS)	SHIPPING CODE (WEIGHT/LBS)
CHLORIDE (Continued)				
7459-01 POL-H	Salinity Direct Reading Titrator	0-20 ppt/0.4 ppt Salinity	50 at 20 ppt (2)	NH (1)
7172-01	Dropper Bottle	1 drop = 10, 25, or 50 ppm Cl ⁻	120 at 100 ppm (5)	R1 (2)
7247	Dropper Bottle	1 drop = 2, 5, or 10 ppm Cl ⁻	120 at 10 ppm (5)	R1 (1)
CHLORINE Free, Combined and Total Chlorine may be determined using DPD with either colorimetric or titrimetric methods. These determinations are generally limited to concentrations of 0-10 ppm, although the FAS titration can test higher concentrations by dilution or with the addition of more DPD indicator. Higher concentrations require the iodometric titration, whereby the sample is acidified and iodide is added, which is oxidized by chlorine to iodine and is titrated with a standard thiosulfate solution. Iodometric determinations will only test total chlorine.				
Free & Total				
3308* SL-26	DPD Tablet Octa-Slide	0.2, 0.4, 0.6, 0.8, 1.0, 1.5, 2.0, 3.0 ppm Cl	50 (2)	NH (1)
3308-LI	DPD Liquid Octa-Slide	0.2, 0.4, 0.6, 0.8, 1.0, 1.5, 2.0, 3.0 ppm Cl	144 (3)	R1 (1)
3312* SL-MW	DPD Tablet Octa-Slide	0.1, 0.2, 0.3, 0.4, 0.5, 0.6, 0.8, 1.0 ppm Cl	50 (2)	NH (1)
3313* SL-SWS	DPD Tablet Octa-Slide	1.0, 1.5, 2.0, 2.5, 3.0, 4.0, 5.0, 6.0 ppm Cl	50 (2)	NH (1)
3314* SL-16	DPD Tablet 2 Octa-Slides	Low: 0.1-1.0 ppm Cl High: 1.0-6.0 ppm Cl	100 (2)	NH (1)
3328 SL-60	DPD Tablet Octa-Slide	1.0, 2.0, 3.0, 4.0, 5.0, 6.0, 8.0, 10.0 ppm Cl	50 (2)	NH (1)
3670-01 DC1200-CL	DPD Tablet Colorimeter	0-4.0 ppm/0.05 ppm Cl	100 (2)	NH (4)
3670-01-LI DC1200-CL-LI	DPD Liquid Colorimeter	0-4.0 ppm/0.05 ppm Cl	144 (3)	R1 (5)
DPD Free Chlorine, Monochloramine, Dichloramine, & Total Chlorine				
3316 SL-1	DPD Tablet Octa-Slide	0.2, 0.4, 0.6, 0.8, 1.0, 1.5, 2.0, 3.0 ppm Cl	50 (4)	NH (1)
DPD Free, Mono & Dichloramines, Total Chlorine, pH				
6980 LP-8	DPD Tablet/ Phenol Red Tablet 3 Octet Comparators	Low: 0.1-1.0 ppm Cl High: 1.0-6.0 ppm Cl pH: 6.8-8.2	200 (5)	NH (7)

**SOLUCIONES TÉCNICAS HIDRÁULICAS SOLTECH LTDA. CALLE 76 No. 20B-24 Of. 302
TEL. 347 5141 FAX. 347 5170 BOGOTÁ D.C. COLOMBIA**

Ship Codes: (NH) Non-Hazardous Material - No Fees • (R1) Small Qty. Hazardous Material - No Fees • (R2 & R3) Hazardous Material - Air Fees Only • (HF) Hazardous Material - Air & Ground Fees
*(NPDWR) EPA Accepted • †(NPDES) EPA Accepted • Direct Reading Titrators have a specific range, but may be refilled to test higher concentrations.